

# APPLICATION INSTRUCTIONS

---

## POLYX<sup>®</sup>-OIL PURE – 5125

### MECHANICALLY WITH A FLOOR BUFFER

Apply two thin coats with an Osmo FloorxCenter<sup>®</sup> or floor-buffing machine, with green and white pads.

**First Coat:** Apply one thin coat with an Osmo Double Sided Scraper, Professional Scraper or other high quality trowel, and Osmo FloorxCenter<sup>®</sup> or single disc floor-buffing machine.

1. Stir the Polyx<sup>®</sup>-Oil Pure well prior to use.
2. Trowel the product thinly onto the floor using an Osmo Double Sided Scraper or similar.
3. Disperse and polish the floor using a floor buffer and green pads.
4. Allow approx. 35-45 minutes for product to penetrate surface
5. Proceed immediately to second coat

**Second Coat:** Immediately after the first coat of Polyx<sup>®</sup>-Oil Pure, apply a second thin coat with a trowel and buffing machine.

1. Trowel the second coat product thinly and evenly onto the floor.
2. Allow approx. 35-45 minutes for product to penetrate surface
3. Disperse and polish the floor, removing excess using a floor buffer and white pads
8. There is too much material on the surface when you can see rings. If so, turn the pad over.
4. Allow 8-10 hours drying time. Allow for good ventilation whilst drying

**If using as a Polyx<sup>®</sup>-Oil Pure 5125 as a top coat over Polyx<sup>®</sup> Professional Colour Oils, proceed immediately to second-coat. Only one coat of Polyx-Oil is required over top of an Polyx<sup>®</sup> Professional Colour Oil therefore the first coat and its steps are omitted.**

*Tip:* 13" (330mm) Pads on an Osmo FloorxCenter<sup>®</sup> will buff around 400ft<sup>2</sup> before they require either flipping, or replacement

## APPLICATION INSTRUCTIONS

---

### CONTINUED – POLYX<sup>®</sup>-OIL PURE – 5125

#### BY HAND WITH SCOTCHBRITE PADS

For small areas and furniture, apply two thin coats with a non-abrasive, white scotchbrite pad and a lint-free cloth.

1. Stir the Polyx<sup>®</sup>-Oil Pure 5125 well and pour a small amount into a disposable container
2. With a white scotchbrite pad work the product into the wood evenly in figure 8 or circular motions
3. Be sure to thinly and evenly coat the surface and leave on the surface for approx. 35 minutes
4. With a clean lint-free cloth, polish the surface ensuring no rings, wipe marks or blotches
5. Ensure all excess product is removed from surface.
6. Approx. 8-10 hours drying time. Allow for good ventilation whilst drying
7. Apply second coat following steps 1-6

**Tinting:** Osmo Polyx<sup>®</sup> Professional Colour Oils can also be used to lightly tint Polyx<sup>®</sup>-Oil Pure 5125 up to a ratio of 10:1. Do not exceed a ratio of 10 parts Polyx<sup>®</sup>-Oil Pure 5125 to 1 part Professional Colour Oil.